

Ghid rapid de utilizare

Camera supraveghere video PNI IP12MP



1.


1. Introducere:

Acest manual este doar un ghid rapid de utilizare pentru camerele cu IP PNI. Pentru informatii mai detaliate, va rugam sa consultati CD-ul inclus in pachet.

2. Descriere produs:



2.



① Alegeti o adresa IP

Adresa IP selectata si alti parametri sunt afisati in partea dreapta a ecranului. Daca aduceti modificari parametrilor de configurare, click pe butonul "Modify" pentru a salva.

NOTA: Camera video trebuie sa fie in aceeasi retea cu router-ul. Faceti click pe butonul "Same to PC" pentru a importa toti parametrii de retea ai PC-ului (Subnet Mask si Gateway).

4.

3. Pornirea dispozitivului si configurare IP:

3.1 Pornirea dispozitivului
NOTA: Folositi doar un alimentator de 12V 2A sau similar. Dupa alimentarea la curent si la reteaua de internet, asteptati 50 de secunde inainte de a folosi camera.

3.2 Configurare IP

[Adresa IP]: implicit 192.168.1.10
[Subnet Mask]: implicit 255.255.255.0
[Default Gateway]: implicit 192.168.1.1

Deschideti CD-ul din pachet si instalati software-ul General Device Manager.

Apoi click pe [IP search]. Pe ecran vor fi afisate toate adresei IP online ale dispozitivelor de monitorizare din retea.

4. Acces camera:


4.1 Acces prin Internet Explorer

Deschideti Internet Explorer, introduceti adresa IP in bara de adresa a browser-ului sub forma: http://192.168.1.10
Introduceti nume utilizator si parola. Valorile implicate sunt:

- utilizator: admin
- parola: incompletat

Va recomandam sa schimbiati parola de administrare imediat dupa prima logare in sistem.

Dupa autentificare, accesati [Stream menu] pentru a seta fluxul video principal si secundar.



① Afisare canal ⑤ Meniu principal

② Previzualizare ⑥ Control PTZ

③ Divizare ecran ⑦ Istoric evenimente

④ Volum

Accesati [Main menu] ->[System] ->[Device Manager] pentru a adauga o camera.
Nota: Manualul complet de utilizare al software-ului CMS il gasiti pe CD-ul inclus in pachet.

5.

4.3 Accesare prin dispozitive mobile

Retea compatibila: WiFi
Sistem de operare: Android, iOS
Aplicatie: XMeye

Nota: Manualele de utilizare ale aplicatiilor le gasiti pe CD-ul inclus in pachet.



Xmeye



iPhone APP



Android APP

6.

4.2 Acces software CMS

De pe CD-ul inclus in pachet, instalati software-ul de management (General CMS):

b. Dublu click pe iconita CMS, introduceti nume utilizator si parola.

Valori implicate:

- Utilizator: super
- Parola: incompletat

8.

4.4 Acces prin Cloud

a. Accesati pagina <http://xmeye.net>. Autentificati-v-a:

Please Click "Enter Guide" if you visit first
Register Download Get Password

b. Adaugati camera video urmand indicatiile



9.

c. Click Login pentru a accesa interfata Cloud. Faceti click in partea stanga a ecranului pe o camera pentru previzualizare.



d. Dupa ce ati configurat in mod corect camera, o puteti accesa de oriunde atat timp cat aveti acces la internet.

NOTA: Semnul rosu din partea stanga a ecranului de previzualizare indica faptul ca respectiva camera video nu este conectata la serviciul cloud.

10.

5. Intrebari si raspunsuri:

5.1 Instalare ActiveXIE

Instalare ActiveXIE in Windows 7

- Reduceti nivelul de securitate al computerului. In meniul principal rulati comanda "msconfig", schimbati setarile UAC, click "Enable", selectati "Never notify".
 - Setati nivelul de securitate IE
- Accesati Control Panel>Network and Internet>Network and Sharing Center>Internet Options. Selectati nivelul de securitate. Activati Toate optiunile ActiveX.

Instalare ActiveX IE in Windows XP

- In sistemele de operare XP este necesara doar setarea nivelului de securitate (respectati pasii descrisi la Windows 7)

12.

5.5 Sunteti autentificat in serviciul de Cloud, dar nu puteti previzualiza camera.

Cauza: ActiveX nu este instalat. Instalati plug-in-ul ActiveX conform indicatiilor din acest manual (punctul 7.1).

14.

5.2 Mutarea obiectelor in cadrul genereaza o umbra in afisarea pe ecran.

Cauza: dupa activarea obturatorului electronic, rata de frame-uri este prea mica.

Accesati [Device config]->[System settings]->[Camera parameters] si dezactivati "Electronic shutter".

5.3 Actualizare nereusita

Cauza: Firmware-ul este incompatibil cu modelul camerei video. Contactati distribuitorul dumneavoastra pentru a obtine o versiune de firmware compatibila.

5.4 Eroare conectare Cloud

- Accesati [Device config]->[System settings]->[Network settings] pentru configurare DNS
- Inchideti in router filtrul adresei MAC si IP si toate limitarile accesului la retea publica.

11.

6. Specificatii tehnice:

- Senzor CMOS
- Filtru IR-CUT
- Rezolutie 720P
- Sistem video PAL
- Compresie video H.264
- Lentile fixe 3.6mm
- LED-uri IR 24 bucati
- Distanță iluminare IR: 20 m
- Suporta monitorizare de pe dispozitive mobile: iPhone, iPad, Android
- Compatibil cu protocolul ONVIF 2.3
- Port Ethernet 10 / 100 Mbps
- Suporta functia iCloud (P2P)
- Compatibil cu: Internet Explorer
- Inregistrare imagini la distanta pe PC sau NVR
- Temperatura de functionare -20°C ~ +40°C
- Umiditate <95%

13.

15.

16.

Quick guide
Video surveillance camera
PNI IP12MP



1.

1. Introduction:

This operation manual is only for a brief description of the product, for more product information please open the CDROM.

2. Product description:



2.

3. Boot up & IP configuration:

3.1 Boot up

Please use a 12 V 2A power adapter or similar.


Please use the positive power of about 50 seconds of network cameras start complete, the network camera through a cable connected to the LAN.

3.2 IP config

[IP address]:default is 192.168.1.10
[Subnet Mask]:default is 255.255.255.0
[Gateway]:default is 192.168.1.1.

Open the CD and install the software General Device Manager.

Then click [IP search], all online IP addresses of the monitoring devices within the LAN will be searched and displayed.



① Choose one IP address

Choose IP address to config. IP address and port are displayed on the right, you can modify the IP parameters and click "Modify" to save.

Note: IP address of the speed dome must share the same network segment with the router and conform to the router's IP, and make sure the IP is not conflicted in the network of LAN. Go to [conform to local PC] to automatically match subnet mask and default gateway with local computer.

4.


4. Camera access:

4.1 IE Access

Open web browser, enter IP address, take 192.168.1.1 O as an example, input http://192.168.1.10 to connect.

Enter user name and password (default user name is admin, no password). Change the administrator password timely after login.

After successful login, go to [stream menu] to connect main stream or substream.



① Main menu

③ PTZ control

5.

② Stream selection ④ Shortcut menu


Note: Plug-ins need to be installed if you login via IE browser. IE is default to intercept plug-in.

Please set IE security level. Go to <internet options>--<security>--<Customized level>-<ActiveX >, enable them all. Or go to our official website to download and install plug-ins (<http://flwww.xmeye.net>); Or get it from the CD and install IE plug-in _V1.1.0.78.exe.

4.2 CMS access

1. Open the CD, double-click Setup.exe, go to [English] > [Software]> [CMS] to install centralized network video management software.CMS shortcut icon will be displayed when installed successfully.

2. Double-click CMS shortcut icon, input user name and password(user name: super, no password) to login.



① Channel display ⑤ Main menu
② Preview ⑥ PTZ control
③ Screen-split ⑦ Log display
④ Volume

3.Go to [Main Menu] > [System] > [Device Manager] to add camera.

Note: The CMS detailed user manual can be found on the CD included in the package.



Xmeye



iPhone APP



Android APP

6.

7.

4.3 Mobile Access

Network environment: WIFI
Mobile system: Android, iOS
App name: Xmeye

Note: The detailed user manual of the mobile applications can be found on the CD included in the package.

8.


4.4 Cloud access

a. Visit <http://xmeye.net>.

Login:

The screenshot shows a login form titled "Login And Preview". It has two tabs at the top: "By User" (selected) and "By Device". The "By User" tab contains fields for "Username" (Username Or E-Mail), "Password", and "Verify" (with a placeholder "3029"). There is a "Remember" checkbox, a "Login" button, and a "Enter Guide" link. Below the form, there is a note: "Please Click "Enter Guide" if you visit first". At the bottom, there are links for "Register", "Download Get Password".

b. Install it step by step according to the guides prompt message.



9.

c. Click "Login" to enter cloud service interface, double-click left camera with alias name to connect to the preview.



d. After successful configuration, wherever and whenever you are, as long as you can surf the Internet, you can get access to the device.

NOTE: When left device name shows with red cross, it means speed dome is not connected with cloud service website.

5. Q&A:

5.1 IE ActiveX installation

IE ActiveX installation in WIN7

- Lower PC security level: In the main menu, run "msconfig", change UAC settings, click "enable", select "Never notify."

- Set IE security level

Go to Control Panel > Network and Internet > Network and Sharing Center > Internet Options, select the Custom Level; enable all the ActiveX controls and plug-ins.

IE ActiveX installation in XP

In XP system, only need to set IE security level, operation same as Win7.

5.2 Moving object has dragged shadow in the live screen

It's caused

It's caused by insufficient frame rate after enable electronic shutter. In dark

5.5 Cloud server login, but can not get live videos

IEActiveX is not installed, so follow instruction to install ActiveX, please close anti-virus software before installing it, otherwise it will intercept the installations of IE ActiveX or make the installation uncompleted.

Note: Only common questions and solutions are mentioned above, for more information, please contact us directly.

11.

environment, our speed dome camera will open the electronic shutter automatically to get good image, it will come out dragged shadow as lengthen exposure time and lower stream, and you can go to <device config>-<system settings>-<camera parameters> to close •electronic shutter-

5.3 Upgrade failed

Upgrade firmware doesn't match product model, please contact us to get the correct one.

5.4 Connect cloud service failed

Go to [Device Config]> [System Settings]> [Network Settings] to config DNS, make sure it shares with LAN router.

2. Turn off the router's MAC address filtering, IP address filtering and other limit connections to public network.

13.

6. Technical specifications:

- Sensor: CMOS
- IR-CUT filter
- Resolution 720P
- Video system PAL
- Fixed 3.6mm Lens
- 34 IR LEDs
- 20m illumination
- Supports: iPhone, iPad, Android
- Supports ONVIF 2.3 protocol
- Port Ethernet 10 / 100 Mbps
- Supports iCloud (P2P) function
- Supports Internet Explorer Browser
- Remote recording on PC or NVR
- Working temperature -20°C ~ +40°C
- Working humidity <95%

10.

12.

14.

16.